Network Protocol Information

UDP Header

Question 1: What is the size of the UDP header?

The UDP header is 8 bytes (64 bits) long.

Question 2: What are the different fields in the UDP header?

The UDP header consists of the following fields:

- 1. Source Port (16 bits)
- 2. Destination Port (16 bits)
- 3. Length (16 bits)
- 4. Checksum (16 bits)

Question 3: Describe the fields in the UDP header.

Source Port (16 bits): The port number of the sending process.

Destination Port (16 bits): The port number of the receiving process.

Length (16 bits): The length of the UDP header and data. The minimum value is 8 bytes (the size of the header).

Checksum (16 bits): Used for error-checking of the header and data.

TCP Header

Question 4: What is the size of the TCP header?

The size of the TCP header is a minimum of 20 bytes (160 bits), but it can be larger if options are used.

Question 5: What are the different fields in the TCP header?

The TCP header consists of the following fields:

- 1. Source Port (16 bits)
- 2. Destination Port (16 bits)
- 3. Sequence Number (32 bits)
- 4. Acknowledgment Number (32 bits)
- 5. Data Offset (4 bits)
- 6. Reserved (3 bits)
- 7. Flags (9 bits)
- 8. Window Size (16 bits)
- 9. Checksum (16 bits)
- 10. Urgent Pointer (16 bits)
- 11. Options (variable length)

Question 6: Describe the fields in the TCP header.

- 1. Source Port (16 bits): The port number of the sending process.
- 2. Destination Port (16 bits): The port number of the receiving process.
- 3. Sequence Number (32 bits):The sequence number of the first byte of data in this segment.
- 4. Acknowledgment Number (32 bits): If the ACK flag is set, this field contains the value of the next sequence number that the sender is expecting to receive.
- 5. Data Offset (4 bits): The size of the TCP header in 32-bit words.
- 6. Reserved (3 bits):Reserved for future use and should be set to zero.
- 7. Flags (9 bits):Control flags such as URG, ACK, PSH, RST, SYN, and FIN.
- 8. Window Size (16 bits):The size of the receive window, which specifies the number of bytes that the sender is willing to receive.
- 9. Checksum (16 bits):Used for error-checking of the header and data.
- 10. Urgent Pointer (16 bits):If the URG flag is set, this field points to the sequence number of the byte following urgent data.
- 11. Options (variable length): Optional additional fields that can extend the header size.

Capturing Packets in Wireshark

<u>Question 7</u>: Locate a UDP packet in Wireshark and relate the values to the fields. UDP-Packets-Wireshark

```
Frame 13: 96 bytes on wire (768 bits), 96 bytes captured (768 bits) on interface \Device\NPF {8D44E5C3-21A6-415F-A343-6B9E6FBC225F}, id 0
Ethernet II, Src: Intel f7:57:fb (b0:3c:dc:f7:57:fb), Dst: TaicangT&WEl 60:c9:2a (78:4f:24:60:c9:2a)
Internet Protocol Version 6, Src: 2404:7c00:4a:5352:5ce:72c4:8fec:4251, Dst: 2404:6800:4007:81d::200e
▼ User Datagram Protocol, Src Port: 61313, Dst Port: 443
    Source Port: 61313
    Destination Port: 443
    Length: 42
    Checksum: 0x32e3 [unverified]
    [Checksum Status: Unverified]
    [Stream index: 0]
  ▼ [Timestamps]
        [Time since first frame: 0.014292000 seconds]
       [Time since previous frame: 0.014292000 seconds]
    UDP payload (34 bytes)
 Data (34 bytes)
    Data: 43f526dfb67ff65b7782841ba3b794bf4912c4e8b0e6075bfaff8cf62123758d703e
    [Length: 34]
```

Relate the values to the fields:

- 1. Source Port: 54060 (0xd31c) The port number of the sender.
- 2. Destination Port: 443 (0x01bb) The port number of the receiver.
- 3. Length: 1232 (0x04d0) The length of the UDP header and payload.
- 4. Checksum: 0x4e86 The checksum value for error-checking.

Question 8: Locate a TCP packet in Wireshark and explain why the fields have the values they have.

TCP_Packets-Wireshark

```
Frame 19: 54 bytes on wire (432 bits), 54 bytes captured (432 bits) on interface \Device\NPF {8D44E5C3-21A6-415F-A343-6B9E6FBC225F}, id 0
Ethernet II, Src: Intel_f7:57:fb (b0:3c:dc:f7:57:fb), Dst: TaicangT&WEl_60:c9:2a (78:4f:24:60:c9:2a)
Internet Protocol Version 4, Src: 192.168.1.75, Dst: 204.79.197.222
Transmission Control Protocol, Src Port: 50816, Dst Port: 443, Seq: 1, Ack: 1, Len: 0
   Source Port: 50816
   Destination Port: 443
   [Stream index: 5]
  [Conversation completeness: Incomplete (20)]
      ..0. .... = RST: Absent
     ...1 .... = FIN: Present
     .... 0... = Data: Absent
      .... .1.. = ACK: Present
      .... ..0. = SYN-ACK: Absent
      .... 0 = SYN: Absent
      [Completeness Flags: ·F·A··]
   [TCP Segment Len: 0]
   Sequence Number: 1 (relative sequence number)
   Sequence Number (raw): 2504637719
   [Next Sequence Number: 2 (relative sequence number)]
   Acknowledgment Number: 1 (relative ack number)
   Acknowledgment number (raw): 542912475
   0101 .... = Header Length: 20 bytes (5)
 Flags: 0x011 (FIN, ACK)
   Window: 1021
   [Calculated window size: 1021]
   [Window size scaling factor: -1 (unknown)]
   Checksum: 0x543c [unverified]
   [Checksum Status: Unverified]
   Urgent Pointer: 0
 | [Timestamps]
```

Explain the fields:

- 1. Source Port: 443 (0x01bb) The port number of the sender, typically a well-known port for HTTPS.
- 2. Destination Port: 53284 (0xd024) The port number of the receiver, typically a high-numbered ephemeral port.
- 3. Sequence Number: 1 The sequence number of the first byte in this segment.
- 4. Acknowledgment Number: 26 The next sequence number the sender expects to receive.
- 5. Flags: 0x010 (ACK) Control flags indicating the state of the connection.
- 6. Window Size: 303 The size of the sender's receive window.
- 7. Checksum: 0xcc16 The checksum value for error-checking.
- 8. Urgent Pointer: 0 Points to the sequence number of the byte following urgent data if the URG flag is set.
- 9. Options: No-Operation (NOP), Timestamps Optional fields used in the header.